


PART SECTION
(TYPICAL)PART SECTION THRU
BEVEL PLATEPART SECTION THRU
BEVEL PLATE


Note: Bevel plates shall be used at end bents when the grade of the slab at expansion device is 3% or more.




PART SECTION A-A





PART SECTION AT END BENT



PERMISSIBLE FIELD SPLICE AT END BENT



PART PLAN OF
ANGLE AND BAR

PART PLAN ROADWAY PLATE
AND VERTICAL PLATE

PART ELEVATION
AT END OF
BEVELED CURB
BENT PLATE

PART SECTION B-E

ELEVATION OF BARRIER CURB
DETAILS OF FLAT PLATE EXPANSION
DEVICE AT END BENT NO.